

# Stand Locating Tool

## PART NO

TED-ATT-003-01


The Stand Locating Tool can be attached to the front of the main chassis utilising the Front Attachment Pins. The Stand Locating Tool has been designed to move stands around under machinery removing the manual handling element, and removing the need for fitters to be under suspended loads whilst placing stands.

## COMPLIES WITH


AS4100, AS3990, AS1554

## SPECIFICATIONS

Attachment Type	TED
Safe Working Load	200/400kg
Mounting	Front
Tare Weight	8kg



SIDE VIEW



END VIEW



[nivekindustries.com.au](http://nivekindustries.com.au)

[sales@nivekindustries.com.au](mailto:sales@nivekindustries.com.au)

+61 (0)400 675 531



**NIVEK**  
**INDUSTRIES**  
PTY LTD